



319-2 Front Upper Coil-Over Mounts/Bearing Style





- Front Upper Frame Mounts for Bearing Style Coil Overs
- Bolts onto backside of upper cross-shaft frame mount to locate (welding after this is recommended)
- Converts upper shock stud mount to a bearing style upper shock mount (1" wide x 1/2" ID)
- Does away with the sloppy stud / rubber bushing type upper coil over mount
- Does away with the flattening of the rubber bushings that tends to happen over time on coil-over setups
- More precise suspension movement is the direct result (no more rubber bushing slop to account for)
- Uses any 1" wide x 1/2" ID upper shock mount. We recommend **4" Stroke shocks** for most applications (Note: AFCO shocks require their "Z" Rod upper shock mount for vehicles wanting a low front ride height 319-FADCOBB)
- Includes (2) Grade 8 shock bolts / nylocks, LH upper mount, RH upper mount, (2) travel limiter bolt pad brackets