



Upper Ball Joint Installation with TRZ Pro-Style Uppers

Ball joint manufacturers have made ball joints more generic these days so that one size fits all.

Some upper ball joints we use are a tight fit in the ball joint cup

Slide the ball joint pin thru the TOP of the a-arm



You will align the ball joint in the cup by using the top two bolts / holes

- Put the supplied washers under the hex side of the bolt against the ball joint
- Put the lock washer & nut on the other side

Then slide the lower bolts into place

- Slowly tighten the nuts in a pattern to avoid damaging the threads



Some ball joints include washers to account for variations in spindle taper



Use them as seen below **IF NECESSARY**



TRZ G-body / S10 / 70-81 F-body / 75-79 X-body Nova: K5208 upper ball joints
TRZ 67-69 F-body / 68-74 X-body Nova / 64-72 A-body / c5 & c6: K1508 upper ball joints